



INSTALLATION GUIDE 10 m Roll

1. Cut tape to the right length before placing. The length should be a little longer than needed. Leave the back layer of the tape on. Clean the site where the tape will be installed.
2. During the installation to the site, gradually peel back the backside of the tape. Do not remove the backside layer completely before the installation because oil, spills, dust can cause adhesion problems.
3. If you have to install the tape at a place where there is no smooth surface, wrap tape two (2) or more times around the pipe or equipment in order to protect against splashes.
4. During the installation, continue to wind the tape making sure to cover a minimum of 1/3 of the former area of the installed tape. You do not need extra force for the application of the tape; however, a little pressure by hand will not harm the installation.
5. Use a knife or scissors to remove SprayStop tape. Removed tape cannot be reused!
6. Punch a drain hole in the tape after installing.

! Note: ! not a seal for leakage!