



## **INSTALLATION GUIDE Flange Set**

1. Clean the site where the tape will be installed
2. During the installation take the widest tape, center it on the flange wind it loosely without force around the flange 2 times. Gradually peel back the backside of the tape. Do not remove the backside layer completely before the installation because oil, spills, and dust can cause adhesion problems
3. When the first Tape is applied, press both sides clockwise towards the tube surface
4. Press the excess tape evenly on the pipe surface
5. Now take one of the narrow tapes and wrap it over the pressed side
6. Punch a drain hole in the tape after installing.

**! Note: ! not a seal for leakage!**